

# Yealink Cordless Handset User Guide




## Call features

### Basic operations

#### Turning Handset On/Off:

To turn the handset on, do one of the following:

- 1) Long press  until the LCD screen lights up.
- 2) Place the handset in the charger cradle. The handset will be turned on automatically.

### To turn the handset off



Long Press  soft key again to turn the handset off.

#### Locking/Unlocking Keypad:

Long press  to lock the keypad.

Long press  again to unlock the keypad.

### Switching silent mode on/off

- 1) Long press  to switch the silent mode on.
- 2) Long press  again to switch silent mode off

