

Yealink Cordless Handset User Guide



Call features

Basic operations

Turning Handset On/Off:

To turn the handset on, do one of the following:

- 1) Long press until the LCD screen lights up.
- 2) Place the handset in the charger cradle. The handset will be turned on automatically.

To turn the handset off

Long Press soft key again to turn the handset off.

Locking/Unlocking Keypad:

Long press # to lock the keypad.

Long press # again to unlock the keypad.

Switching silent mode on/off

- 1) Long press * to switch the silent mode on.
- 2) Long press * again to switch silent mode off

Basic Call Features

Placing Calls:

To place a call directly:

Enter the desired number when the handset is idle, and press (

To Place a call from the local directory:

Press when the handset is idle

Press or to highlight the desired entry and press

If both the office number and mobile number are stored, press or to highlight the desired number, and press 🔽

To place a call from the call history:

- 1. Press the **History** soft key, and select the desired call history list.
- 2. Press or to highlight the desired entry, and press C

To place a call from the redial list:

Press when the handset is idle

Press or to highlight the desired entry and press

Answering calls:

to answer a call, do one of the following:

- Press the Accept soft key
- Press
- Press C

Ending Calls: Press 🙃

Note: You can ignore an incoming call by pressing the Silence soft key or reject an incoming call by pressing



Call Hold and Resume

To place a call on hold:

Press the **Options** soft key during a call, and select **Hold.**

To resume a call, do one of the following:

If there is only a call on hold, press the **Resume** soft key. If there are two calls on hold, press the Resume soft key to resume the current call,

Press the Swap soft key to **swap** between the two calls.

Call Transfer

You can transfer a call in the following ways:

Blind Transfer:

- 1. Press the Options soft key during a call, and select Blind Transfer.
- 2. Enter the number you want to transfer the call to.
- 3. Press the **Transfer** soft key.

Attended Transfer

- 1. Press the Options soft key during a call, and select Transfer.
- 2. Enter the number you want to transfer the call to.
- 3. Press the **Transfer** soft key to dial out.
- 4. Press the **Transfer** soft key after the call is answered.

Customising your phone

Volume adjustment

Press or buring a call to adjust the volume of the currently used audio device.

Press or when the handset is idle to adjust the ringer volume.



Download the Xelion apps

Scan this QR code to download the latest Xelion Apps (mobile and softphone) direct from their website



Watch a demo

Scan this QR code to see a demo video of this handset